

Fault Finding

HRV 1.25, 1.35, 1.75, 2, 2.75, 3, 10 & 10M Units

‘MB’ Models



This document covers part numbers
TP401MB, TP402MB, TP404MB, TP405MB, TP406MB, TP408MB, TP440MB & TP441MB

Contents

Product Identification	3
Product Features	4
Filter Covers	4
Auto Setback Speed	4
Continuous Speed	4
Boost Speed with Overrun Timer	4
Summer Bypass	4
SUMMERboost®	4
Automatic Frost Protection	5
Wiring Diagrams	5
Fault Finding	5
Unit Not Running	5
Unit Trips RCD Or MCB	6
Supply Fan (fan1) Not Running	6
Extract Fan (fan 2) Not Running	6
Unit Will Not Boost	6
Unit Will Not Drop Out Of Boost	7
Unit Speed Drops Below Normal Running Level	7
Excessive Fan/Unit Noise	7
Unit Will Not Respond When Commissioning	7
Unit Does Not Go Into Bypass	7
Required Fan Rates Cannot Be Achieved	8
Moisture/Water On Or Around Unit	8
Moisture Inside The Unit	8
Unit Performance Has Dropped	8
Unit Ramps Up Without Manual Switches Being Operated	8
Cold Air is Being Blown Into The Habitable Rooms	8
PCB Reset	9
Fig 1 Molex Connectors	9
Fig 2 Mains Connection	9
Fig 3 Power PCB	9
Fig 4 Mains Filter	10
Fig 5 Control PCB	10
Fig 6 Testing PCB Inputs	10
Fig 7 Boost Link Test	11
Fig 8 Thermistor Values	11
Fig 9 Thermistor	11
Fig 10 Control PCB Functions	12
Fig 11 Resistor Network	12
Fig 12 Ribbon Cable Connection	12
Fig 13 Replacement PCB where fitted (Firmware FW0040)	13
Auralite	13

Product Identification



All maintenance/fault finding/repairs must be completed by a competent person.

Safe isolation procedures must be followed when working on these units.



Product Features

Model	HRV1.25 Q+	HRV1.35 Q+	HRV1.75 Q+	HRV2 Q+	HRV2.75 Q+	HRV3 Q+	HRV10 Q+	HRV10M Q+
Part number	TP406MB	TP408MB	TP404MB	TP401MB	TP405MB	TP402MB	TP440MB	TP441MB
Filter Covers	●	●	●	●	●	●	●	●
Auto Setback	●	●	●	●	●	●	●	●
Continuous Speed	●	●	●	●	●	●	●	●
Boost Speed - With Overrun Timer	●	●	●	●	●	●	●	●
Summer Bypass	●	●	●	●	●	●	●	●
Ø100 & Ø125mm Ducting	●	●						
Ø125& Ø150mm Ducting			●	●	●	●	●	●
Constant Volume Fans				●		●		
Independent Adjustment Of Fans	●	●	●	●	●	●	●	●
Step Less Fan Speed Setting	●	●	●	●	●	●	●	●
Automatic Frost Protection	●	●	●	●	●	●	●	●

Filter Covers

Some units are fitted with removable filter covers on the front panel.

Auto Setback Speed

Setback Speed is used to reduce ventilation rates. Setback Speed is automatically set at the mid point between minimum possible Continuous Speed and the selected Continuous Speed. The Setback Speed can be enabled by connection of a volt free one-way switch, or combined with the Boost Speed with the 3 position switch TP 508.

Continuous Speed

Continuous Speed is the normal continuous extract and supply air flow running speed of the units.

Boost Speed with Overrun Timer

Boost Speed increases the extract and supply air flow. Boost Speed is configured with Step-less independent fan controls and includes an Overrun Timer variable between 0 and 60 minutes. The Boost Speed can be triggered by any device which provides a volt free one-way switch, such as a PIR, thermostat, humidistat or a standard one-way switch. If the unit is left Boost (latching switch) for longer than 2 hours the Overrun Timer is disabled meaning the HRV will return to Continuous Speed as soon as the switch holding the unit in Boost is released.

Summer Bypass

Summer Bypass is designed to operate during hot periods where fresh air can be vented straight into the property without being preheated by the extracted stale air. Summer Bypass operation is automatically controlled. The Summer Bypass mechanism diverts the stale air being extracted from the dwelling around the heat cell so that its heat energy is not transferred to the fresh air being supplied to the property.

SUMMERboost®

An optional SUMMERboost® facility is available that allows both the supply and extract fans to run at full speed whenever the Summer Bypass is activated.

By default SUMMERboost® is disabled by a Link Wire, see Wiring Diagrams.

Removal of the link wire will enable SUMMERboost®.

When SUMMERboost® is triggered by Summer Bypass the increased fan speed can be prevented either Manually or Automatically.

Manual - This is by means of a volt-free switch wired directly into the controller PCB.




Automatic - This is by means of a dedicated wall mounted room thermostat. SUMMERboost® will only operate when the temperature has exceeded the thermostat setting. Should the room temperature fall below the thermostat setting, then SUMMERboost® will not operate.

Automatic Frost Protection

During very cold weather, Automatic Frost Protection will detect temperatures that could form ice inside the unit. It will reduce the supply ventilation rate to prevent ice build up within the heat cell.

Automatic Frost Protection reduces the flow rate of cold air, thus allowing the warmer stale air to raise the temperature within the heat cell to such a level that prevents the formation of ice. As internal temperatures rise Automatic Frost Protection will increase the supply ventilation flow rate back to the commissioned settings.

Wiring Diagrams



Check the Control PCB has the correct version of software

The PCB should be marked 'FW0012-.....' or 'FW0040.....', see fig 5.

Fault Finding

Unit Not Running

1. Check the continuity across the fuse & that mains power is present at the two pole spur. (Fig 2 & wiring diagram)
2. Check the fuse on the power PCB for continuity - (Fig 3)
3. Check the power on the Power PCB (Fig 3) across the 'power supply to fans' terminals and check if the LED is lit.
4. Check the connection of the ribbon cable joining the power PCB to the control PCB, figs 3 & 4.
5. Isolate power at spur, remove front cover or ducting from stale air to atmosphere and fresh air to habitable rooms spigots. Check if fans will run freely. Check for obstructions.
6. KEEPING Hands away from the unit switch on power, wait approx. 40 sec and look to see if fans are spinning, 'kicking' or are stationary
7. If 'kicking' or are stationary there is a likely to be a PCB or fan fault.
8. Disconnect fan 1 Molex (Supply) connector from the PCB (Fig 5), does fan 2 run? If yes fan 1 faulty. If no reconnect.
9. Disconnect fan 2 Molex (Extract) connector from the PCB (Fig 5), does fan 1 run? If yes fan 2 faulty. If no reconnect.
10. If disconnecting fans has not resolved the issue, then either the PCB and/or both fans are faulty.

11. Check the fans run (see fig 1), turning the potentiometer adjusts speed from max to min or vice versa.
12. Check the resistance across the boost & setback terminals on PCB (this checks if the circuit has been damaged and caused a knock on affect to damage the PCB operation), see fig 6.

Unit Trips RCD Or MCB

1. Disconnect both fans from the 'power supply to fans' terminals Fig 3. Try powering up the unit, if the power does not trip there is a fault with one fan or both fans. If it trips then there is an issue with the power supply PCB, supply cable, external wiring or filter (where fitted).
 - o If it has not tripped connect in turn both fans back into the mains supply terminal Fig 3, Try powering up with each fan, to determine which fan(s) is causing the fault.
 - o If it has tripped Disconnect the mains supply from the Power PCB fig 3, place the cables into suitable terminal block (3A or greater). Try powering up, if the power does not trip the Power PCB is faulty, if it does trip the fault is with the cable, external wiring or filter (where fitted).

N.B. The most common reason for tripping the unit is water/moisture in the fan(s). There is generally two causes:-

- o The ducting has not been insulated, as required by DVCG

The condensation drain has not been sealed, as required in the manual.

Supply Fan (fan1) Not Running

1. Is the unit in Summer Mode, is there a link across SW1.
2. Check Molex connector Fan 1 is firmly pushed onto PCB (fig 5)
3. Is the unit in frost protection mode? Fresh air in Thermistor will measure greater than 23KΩ.
4. N.B. the unit can be forced into Frost Protection by attaching a variable resistor network to the Control PCB Fresh Air In Thermistor terminals (see fig 5) and adjusting resistance until it is above the resistances stated above, see fig 11 for resistor network.
5. Isolate power at spur, remove front cover or ducting from fresh air to habitable rooms spigots. Check fans will run freely. Check for obstructions.
6. KEEPING Hands away from the unit switch on power, wait approx. 40 sec and look to see if fans are spinning, 'kicking' or are stationary.
7. Disconnect the Molex connectors for both fans, put Molex connector from fan 1 onto the PCB connector for fan 2. If the fan runs then the PCB is faulty if the fan does not run the motor is faulty.
8. Check the fan runs (see fig 1), turning the potentiometer adjusts speed from max to min or vice versa.
9. Check resistance across boost and setback terminals on PCB (this checks if the circuit has been damaged and caused a knock on affect to damage the PCB operation), see fig 6

Extract Fan (fan 2) Not Running

1. Check Molex connector Fan 2 is firmly pushed onto PCB (fig 5)
2. If still not running isolate power at spur, remove front cover or ducting from stale air to atmosphere spigot. Check fans will run freely. Check for obstructions.
3. KEEPING Hands away from the unit switch on power, wait approx. 40 sec and look to see if fans are spinning, 'kicking' or are stationary.
4. If still not running disconnect the Molex connectors for both fans, put Molex connector from fan 1 onto the PCB connector for fan 2. If the fan runs then the PCB is faulty if the fan does not run the motor is faulty.
5. Check the fan runs (see fig 1), turning the potentiometer adjusts speed from max to min or vice versa.
6. Check resistance across boost & setback terminals on PCB (this checks if the circuit has been damaged and caused a knock on affect to damage the PCB operation), see fig 6.

N.B. The most common reasons for the extract fan failing are, that the duct to atmosphere is not fully insulated or the condensation drain is has no trap and is not air sealed

Unit Will Not Boost

1. Is a boost setting required – is the continuous requirement higher or the same as the boost requirement?
2. Is it actually boosting but the boost speed is just higher or the same as continuous speed, therefore no audible difference.
 - o Check flow rates at continuous and boost to see if there is a difference.
 - o Change units speed to determine if the difference is then audible.



Unit speeds can be determined by looking at the top of the relevant potentiometer and seeing where the arrows point. If the arrows on the continuous and boost pots are in the same or similar positions the flow rates and noise will be similar.

Turning Anticlockwise – decrease speed

Turning Clockwise – increase speed

3. Is the unit already running at full speed?
4. Is a boost switch fitted?
5. Are boost cables connected to correct terminals (fig 5 & wiring diagrams)?
6. Is the boost switch providing a connection across the boost terminals?
 - o Disconnect the boost wires and check for continuity, with a continuity tester or multimeter.
 - o The boost function can be tested by bridging the boost terminals, using a link wire, see fig 7.

7. If using momentary switches, is over run timer set to zero?
8. Is the unit in commissioning mode? Programming switch should be in the central Run position see fig 5 & 10

Has 230v been incorrectly applied to the PCB (all switching is volt free). The PCB may show signs of damage but not always. If a voltage has been applied, this can be proved by measuring the resistance across the terminals (with cables removed), if open circuit then a voltage has been applied. If a voltage has been applied the PCB will require replacing. It may also result in one or both of the fans requiring replacing, depending whether damage has been limited to the PCB or not (Fig 6).

Unit Will Not Drop Out Of Boost

1. Is the unit in boost commissioning mode? Programming switch should be in the central Run position see fig 5 & 10
2. Are all boost switches in the OFF position?
3. Is overrun timer set high? After resetting, switch the unit off for 20 seconds and switch back on
4. Boost switch wiring or switch fault – is there permanent continuity at boost terminals.
5. 230v has been applied to boost terminals – control circuitry has been damaged. Check as Fig 6
6. Where room or in duct humidity sensors are fitted, the humidity within property is sufficiently high to continuously activate the unit. Increase the humidity trigger point, then switch the unit off for 20 seconds then put back on.
7. If fitted, proximity sensors are continuously being triggered by movement.

N.B. If the mains cable and boost cables are run in close proximity it is possible the 230v can induce a voltage into the boost cables and result in the unit not dropping out of boost. Five core cable – live, neutral, earth and two for boost must not be used.

Unit Speed Drops Below Normal Running Level

1. Is the unit in setback mode, check switches/wiring Fig 5 & wiring diagrams.
2. Is the unit in frost protection mode? Fresh air in Thermistor will measure greater than 23KΩ.
3. If the thermistor temperature is incorrect replace the thermistor.

Excessive Fan/Unit Noise

1. Has the unit been set to the correct continuous flow rates and running in continuous mode, if yes are the speeds higher than predicted (reference unit fan curves – available on our web site). If yes check for excess resistance/leakage:-
 - o Is there excess flexible ducting or tight bends?
 - o Are all ducts connected and sealed?
 - o Are ducts sizes correct?
 - o Are external terminals (roof terminals or air bricks) suitable for the application?
 - o Have ceiling terminals be wound too far in?
 - o Are there any deviations from the design?
 - o Are there any blockages in the ducting or in the air ways in the unit?
 - Has the unit been mounted on a stable surface using the mounting brackets provided?
 - Is the unit horizontally & vertically square?
2. Isolate power at spur, remove front cover or ducting from stale air to atmosphere and fresh air to habitable rooms spigots. Check fans will run freely, with no unexpected bearing noise or signs the fan is hitting/rubbing against its housing.

N.B. HRV2&3. The set speeds may be correct but resistance is causing the fans to run at a faster speed to achieve the required flow rate (constant volume motors). Remove ducting to the unit, one duct at a time. If the fans speed drops dramatically then there is excessive resistance in that duct run

Unit Will Not Respond When Commissioning

3. Unit not in the commissioning mode – program switch has not been moved, see Fig 10
4. Check position of the potentiometers – N.B. Boost cannot be set lower than Continuous & Continuous cannot be set higher than Boost.
5. Unit reset
 - o Turn both Continuous potentiometers to minimum
 - o Turn both Boost potentiometers to maximum
 - o Push the program switch fully to the right, then fully to the left, then back to the middle.
6. Has 230v been applied to the boost terminals? See fig 6
7. HRV2 & 3 Remove the ducting from the unit and check if the fans then respond

Unit Does Not Go Into Bypass

1. Is the measured resistance of the thermistor between 12.09 KΩ & 10.38 KΩ

N.B. Thermistor must be disconnected from the PCB when checking.
2. Has the thermistor become disconnected or its cable damaged Fig 9.
3. Is the ribbon cable attached (check continuity of the cable) Fig 3 & 4.
4. Is there 240v across the Bypass terminals Fig 3

N.B. the unit can be forced into Bypass by attaching a variable resister network to the Control PCB thermistor input (see fig 5) and adjusting the resistance until it is between resistances stated above.

Required Fan Rates Cannot Be Achieved

1. Incorrect unit selected – refer to unit literature for unit capability.
2. Excess resistance/leakage:-
 - o Is there excess flexible ducting and/or tight bends?
 - o Are all duct connected and sealed?
 - o Are ducts sizes correct?
 - o Are external terminals (roof terminals or air bricks) suitable for the application?
 - o Have the ceiling terminals been wound too far in?
 - o Are there any deviations from the design?
 - o Are ducting joints sealed (silicone or other recognised method)?
 - o Are there any deviations from the design?

Are there any blockages in the ducting or in the air ways in the unit

Moisture/Water On Or Around Unit

1. Are the ducts to atmosphere insulated from the top of the unit to the underside of the roof (roof terminal) or to the brickwork (airbrick)?
2. If the stale to atmosphere rises vertically to a roof terminal is a condensation trap fitted?
3. If the ducts from the unit to the wet rooms and/or those to the habitable rooms pass through a cold void are they insulated?
4. Is the internal condensation tray split?
5. Is the unit fitted square both horizontally and vertically?
6. Is the condensation drain fitted?
7. Is the condensation drain fitted with a proprietary trap and pipe sealed to the trap?
8. Does the condensation drain run have a minimum of 5° fall?
9. Has the ducting been connected to the correct unit spigots?

Moisture Inside The Unit

It is usual to find water in the condensation tray and within the heat recovery cell, especially after there has been high humidity within the Kitchen or Wet Rooms. The unit will dry itself after a reasonable period.

If water is found in the fan scrolls, underneath the tray, around the fan EPP or in the vicinity of the PCB's this indicates there is an issue with the installation.

Check the following.

1. Are the ducts to atmosphere insulated from the top of the unit to the underside of the roof (roof terminal) or to the brickwork (airbrick)?
2. If the stale to atmosphere rises vertically to a roof terminal is a condensation trap fitted?
3. If the ducts from the unit to the wet rooms and/or those to the habitable rooms pass through a cold void, are they insulated?
4. Is the internal condensation tray split?
5. Is the unit fitted square both horizontally and vertically?
6. Is the condensation drain fitted?
7. Is the condensation drain fitted with a proprietary trap and the pipe sealed to the trap?
8. Does the condensation drain run have a minimum of 5° fall?
9. Has the ducting been connected to the correct unit spigots?
10. Is there moisture on or inside the ducts.

Unit Performance Has Dropped

1. The filters have become clogged.
2. Flexible ducting has been crushed.
3. Rigid ducting has been knocked or moved resulting in air leakage.
4. Ceiling terminals have been tampered with.
5. Airbricks and /or roof terminals have become blocked or restricted.

Unit Ramps Up Without Manual Switches Being Operated

1. If an external humidity sensor is fitted, humidity within property has increased sufficiently to trigger boost. Increase the humidity trigger point to prove.
2. If PIR's are fitted are these being triggered.

Cold Air is Being Blown Into The Habitable Rooms





1. Has the air temperature been measured and compared with the air temperature in the wet rooms. The difference should be approx. 2-3°C. *Moving air does feel cold!*
2. Are the correct type of ceiling terminals fitted?
3. If the ducts from the unit to the wet rooms and/or those to the habitable rooms pass through a cold void are they insulated?
4. Is the unit in bypass mode?
5. Are the supply and extract rates balanced, i.e. is the supply rate dramatically higher than the extract rate.

PCB Reset

1. Rotate the Supply and Extract Continuous Speed potentiometers fully anticlockwise
2. Rotate Supply and Extract Boost Speed potentiometers fully clockwise move the Run/Program Switch from the Run position to the Continuous position, from the Continuous position to the Boost position and back to the Run position. To ensure that the reset switch movements are registered by the controller wait two seconds between each switch movement.
3. Rotate the overrun timer fully anticlockwise
4. Rotate the humidity sensor fully clockwise


Switch the power off to the unit for a minimum of 20 seconds then switch back on.
The unit will go through a ramp up routine then after approx. 40 seconds it will run as determined by any internal/external inputs.

Fig 1 Molex Connectors

		 AB CD Insertion End		 DCBA
10KΩ Potentiometer Connections	Molex Fan Connector A - 10V, B - 0V, C - PWM & D - Tacho		PCB Connector	


Connect a 10KΩ Potentiometer across the terminals shown and rotate to check if the fan will respond. If this is not possible, try bridging the A and C terminals on the fan connector, the fan should then run at full speed.


Fig 2 Mains Connection



Wiring diagram

Fig 3 Power PCB





Lit LED denotes 12Volts is present.





Ribbon Cable

Fig 4 Mains Filter



Mains filter

Fig 5 Control PCB



Molex Fan 1 Supply
Molex Fan 2 Extract

Not Used
(SW1)

Boost
(SW2)

Setback
(SW3)


Thermistor
Fresh Air
(temperature)

Firmware Version
Unit Specific

Ribbon Cable connector

Programming Switch

Fig 6 Testing PCB Inputs



Measure resistance across the terminals, this is easier across the soldered joints rather than the terminals block.

If reading is open circuit, it is probable that 230v has been applied.


If reading is approx. 15kΩ, then the circuit is ok.

This only checks the switch input circuits and does not prove overall functioning i.e. PCB may still be faulty if reading is approx. 15kΩ



Damage to component

Fig 7 Boost Link Test



Boost Link

Fig 8 Thermistor Values

Temp °C	Resistance (KΩ)
-10	42.47
-9	40.57
-8	38.77
-7	37.06
-6	35.44
-5	33.90
-4	32.44
-3	31.05
-2	29.73
-1	28.48
0	28.48
1	26.13

Temp °C	Resistance (KΩ)
2	25.03
3	23.99
4	23.00
5	22.05
6	21.15
7	20.30
8	19.48
9	18.70
10	17.96
11	17.24
12	16.56
13	15.90

Temp °C	Resistance (KΩ)
14	15.28
15	14.69
16	14.12
17	13.58
18	13.06
19	12.56
20	12.09
21	11.63
22	11.20
23	10.78
24	10.38
25	10.00
26	9.63

Fig 9 Thermistor



Fig 10 Control PCB Functions




Fig 11 Resistor Network






Fig 12 Ribbon Cable Connection



N.B. For simplicity the photo's show the ribbon cable disconnected, however measurement should be taken with it connected.

Fig 13 Replacement PCB where fitted (Firmware FW0040)



Auralite

Fault Finding can be aided by fitting an Auralite indicator TP518. This will give an indication of which mode the unit is running in.



Normal - the system is running at continuous speed. (normal mode) or the unit is running at setback speed if this light is flashing

Frost - the unit is in automatic frost protection mode.

Filter - the filters require changing


Boost - the system is running in boost speed.

If flashing indicates boost alert

Summer - the unit is in summer bypass mode

Fault - there is a fault with the system and the installer should be contacted.

- o Auralite cable termination fault or incorrect wiring
- o Fan Fault – This generally falls into one of 2 faults, the fan is actually not running or there is tacho signal error. Check if the fans are running and check the Molex connectors are firmly connected onto the control PCB (see fig 5). If the fans are running this will mean there is a tacho issue and one of the fans need replacing, unfortunately this fault indication does not indicate which fan is causing the fault.
- o Control PCB fault



Reference Documents

Approved Document Part F
 Domestic Ventilation Compliance Guide (DVCG)

Available from <https://www.gov.uk/government/publications/ventilation-approved-document-f>