



# TP631 INSTALLATION GUIDE



Cut a 360 x 510mm ceiling aperture in the required position.

1




Mount the purge unit as guided in the Purge Unit Manual ensuring the dimensions above with the aperture.

2




Attach the supplied guard to the purge unit's motor fixings points.

3



Attach the ceiling cover plate to the purge unit with the (4x supplied) M5x20 fixings and square the plate with the wall.

4





Finally attach the extract ceiling terminal to the cover plate.


5



A



B



SLOT TO ALLOW FOR ANGULAR  
ADJUSTMENT OF THE COVER.

COVER PLATE TO UNIT FIXING

EXTRACT TERMINAL FIXING

B ( 1:2 )

